


FÜR HANDWERK. DAS ÜBERZEUGT.

Technical Data Sheet

BLANKE FLOOREX

Profile for small and wide expansion joints for indoor and outdoor use





Technical Data

Supplied length: 2.50 m (light grey, sand-

grey, bahama beige,

anthracite),

3.0 m (light grey)

Heights: 8.0 mm

10.0 mm 12.5 mm

Joint widths: 5.0 mm

8.0 mm

Overall width: 48.0 mm
Profile thickness: 0.8 mm
Expansion: about 20%
Colours: light grey p

light grey plastic, sand grey, bahama beige,

medium grey, anthracite

Mechanical load capacity: up to 2 kN/m²

Characteristics

- > low gloss finish of plastic joints
- > lateral interlocking closure
- > fungus- and bacteria-resistant
- > UV-resistant
- > available in two widths

Description

BLANKE FLOOREX is an expansion joint profile using a lateral interlocking closure. Its plastic joints have a low gloss appearance and are made of plastic. They are used for the installation of ceramic floor tile covers. The attachment legs are made of unplasticised PVC. They are anchored underneath the floor tiles in the thin adhesive layer. Any movement will be transferred in the direction of that movement. Any pressure, tension, and change in height is absorbed. When removing a perforated side strip (predetermined breaking point), the BLANKE FLOOREX is perfectly suited as flexible connecting joint facing existing components. The upper and lower expansion zones are made from soft and highly-flexible PVC.

Aplication area

BLANKE FLOOREX is used as expansion joint for tiled floors using a process that applies a thin layer of adhesive. Perfectly suitable as wall connection against window frames or door casing; for floor coverings against existing wall and foundation cover and door elements.

Working instructions

Press the BLANKE FLOOREX perforated attachment legs into the adhesive layer and align the legs properly. Expansion joints from the sub-floor must be of the same height. Use a putty knife to cover the attachment legs with tile adhesive compound and press the tile firmly into the adhesive. Ensure the upper edge of the profile is flush with the tile. In the profile area, the tiles must be installed in a solid bed. Create a gap about 1.5 mm wide between the tile and the profile, and fill it with grout.

Verfasser: AWT 02.05.2013

Attention: The proper and successful application of our products is outside our control. Therefore, we can only guarantee the quality of our products within the scope of our terms and conditions. However, we cannot be held responsible for the successful application of our product. This data sheet shall render all previous technical information about this product invalid. We reserve the right to changes based on technical advancements. Information that exceed the scope of this bulletin and is provided by our staff, requires our written confirmation.

Blanke GmbH & Co. KG